



**SPECIFICATIONS**  
仕 様

PLUNGER STROKE プランジャストローク		11.1 mm
JAW STROKE (IN DIA) ジョーストローク(歯幅)		7.7 mm
GRIPPING FORCE 把握力	AIR PRESSURE エア圧力 0.8 MPa (8kgf/cm <sup>2</sup> )	19 kN (1937 ksf)
	OIL PRESSURE 油圧力 1.3 MPa (13kgf/cm <sup>2</sup> )	53 kN (5404 ksf)
MAX PERMISSIBLE PRESS 最高使用圧力	AIR PRESSURE エア圧力	0.7 MPa (7kgf/cm <sup>2</sup> )
	OIL PRESSURE 油圧力	1.3 MPa (13kgf/cm <sup>2</sup> )
MIN PERMISSIBLE PRESS 最低使用圧力		0.2 MPa (2kgf/cm <sup>2</sup> )
AIR CONSUMPTION (PER 1mm OF PLUNGER STROKE ON PRESSURE OF 0.6MPa) 空気消費量 (プランジャストローク1mmあたり0.6MPa時)		0.54 Nℓ
GRIPPING RANGE 把握範囲	OUTER 外径把握	φ13~φ120
	INNER 内径把握	φ70~φ160
MASS (INCLUDE STANDARD SOFT JAW) 質量 (標準ソフトジョー付)		24 kg

○把握力はジョーおよびワークの把握状態により変化します。  
THE GRIPPING FORCE IS DIFFERENT DEPENDING ON THE GRIPPING STATE.

**注 記**

- 北川チェック専用グリスを取扱説明書にのせてグリスアップしてください。
- シリンダは内径把握、外径把握にかかわらず常に引合側(閉側)で使用してください。押し側(開側)で使用することは避けてください。内外径把握の切替えは、取扱説明書にのせて作業を行う必要があります。

**NOTICE**

- KITAGAWA CHUCK GREASE SHOULD BE LUBRICATED INTO THE CHUCK BODY AT APPROPRIATE INTERVAL REFERRED TO THE INSTRUCTION MANUAL.
- CYLINDER SHOULD BE ALWAYS USED AT RETRACTING-WARD (CLOSE) REGARDLESS OF GRIPPING DIAMETER OF INNER OR OUTER. PLEASE AVOID TO USE AT EXTRACTING-WARD (OPEN). THE CHANGE OF GRIPPING DIAMETER OF GRIPPING DIAMETER OF INNER OR OUTER SHOULD BE DONE WITH REFERING INSTRUCTION MANUAL.

CAREER		SCALE	TYPE	PWS06	WEIGHT	kg
MANAGER	CHIEF	DRAWN BY	1:1	ワークグripper 6	WORK GRIPPER 6	
KITAGAWA IRON WORKS CO.,LTD.		DATE	3rd ANGLE	PWS06 ガイグイ OUTSIDE VIEW		
			DRW NO.	61P-26-5896		